

ELECTROMAGNETIC PULSE (EMP) AND TEMPEST PROTECTION FOR FACILITIES

TABLE OF CONTENTS

	<u>Paragraph</u>	<u>Page</u>
CHAPTER 1. INTRODUCTION		
Scope.....	1-1	1-1
Application.....	1-2	1-1
References.....	1-3	1-1
Background.....	1-4	1-2
Pamphlet organization.....	1-5	1-2
CHAPTER 2. EMP ENVIRONMENT		
Outline.....	2-1	2-1
HEMP: detailed discussion.....	2-2	2-2
Other EMP environments.....	2-3	2-5
Environment-to-facility coupling.....	2-4	2-9
Equipment susceptibility.....	2-5	2-16
Cited references.....	2-6	2-19
Uncited references.....	2-7	2-20
CHAPTER 3. EMP HARDENING CONCEPTS FOR FACILITIES		
Outline.....	3-1	3-1
Discussion of general concepts.....	3-2	3-1
Description of HEMP hardening concepts.....	3-3	3-4
Cited reference.....	3-4	3-10
Uncited references.....	3-5	3-10
CHAPTER 4. SYSTEM ENGINEERING REQUIREMENTS		
Outline.....	4-1	4-1
Standards and specifications.....	4-2	4-1
Electromagnetic integration.....	4-3	4-2
HEMP and lightning protection integration.....	4-4	4-2
HEMP/TEMPEST and electromagnetic integration....	4-5	4-4
Environmental requirements.....	4-6	4-5
Cited references.....	4-7	4-6

CHAPTER 5. FACILITY DESIGN

Outline.....	5-1	5-1
Theoretical approach to shielding.....	5-2	5-5
Shield design methodology.....	5-3	5-6
Solid shields.....	5-4	5-10
Shielded enclosures.....	5-5	5-20
Mesh and perforated type shields.....	5-6	5-21
Layered shields.....	5-7	5-27
Reinforcement steel (rebar).....	5-8	5-27
Earth cover electromagnetic wave attenuation....	5-9	5-30
Shield joints and seams.....	5-10	5-31
Internal cable and connectors.....	5-11	5-35
Conduit and conduit connections.....	5-12	5-38
Terminal protection for electrical penetrations.	5-13	5-43
Apertures.....	5-14	5-52
Utility penetrations.....	5-15	5-55
Bonding.....	5-16	5-55
Grounding.....	5-17	5-61
Cited references.....	5-18	5-64
Uncited references.....	5-19	5-67

CHAPTER 6. EMP AND TEMPEST TESTING REQUIREMENTS

Outline.....	6-1	6-1
Introduction.....	6-2	6-3
Testing requirements versus facility mission...	6-3	6-4
Susceptibility testing.....	6-4	6-4
Quality assurance testing.....	6-5	6-6
Acceptance testing.....	6-6	6-7
Hardness assessment and validation testing.....	6-7	6-9
Life-cycle testing.....	6-8	6-10
Test methodology.....	6-9	6-11
Free-field illuminators.....	6-10	6-12
Current injection testing.....	6-11	6-17
Shielding effectiveness testing.....	6-12	6-27
Bonding impedance measurements.....	6-13	6-34
Cited references.....	6-14	6-35
Uncited references.....	6-15	6-36

	<u>Paragraph</u>	<u>Page</u>
CHAPTER 7. PROTECTION MAINTENANCE AND SURVEILLANCE		
Outline.....	7-1	7-1
Introduction.....	7-2	7-2
Facility life cycle environment.....	7-3	7-2
Hardening shielding elements.....	7-4	7-3
Impact of hardness maintenance on facility design.....	7-5	7-4
Hardness maintenance program structure.....	7-6	7-7
Hardness surveillance (HS) activities.....	7-7	7-10
Cited references.....	7-8	7-13
CHAPTER 8. EMP AND TEMPEST RISKS		
Outline.....	8-1	8-1
Introduction.....	8-2	8-2
EMP environment--overview.....	8-3	8-2
Comparison of HEMP and lightning.....	8-4	8-5
TEMPEST risks.....	8-5	8-5
Cited references.....	8-6	8-10
CHAPTER 9. EMP AND TEMPEST PROTECTION CONCEPTS		
Outline.....	9-1	9-1
Introduction.....	9-2	9-1
TEMPEST requirement in relation to HEMP.....	9-3	9-4
Generic facility hardening.....	9-4	9-5
CHAPTER 10. SYSTEMS INTEGRATION		
Outline.....	10-1	10-1
Introduction.....	10-2	10-1
Protection system integration.....	10-3	10-2
Internal systems.....	10-4	10-2
Environmental systems.....	10-5	10-2
General integration.....	10-6	10-3
CHAPTER 11. DESIGN AND SPECIFICATION PROCESS		
Outline.....	11-1	11-1
Introduction.....	11-2	11-2
Design approach.....	11-3	11-2
Typical design process.....	11-4	11-3
General shield design problem areas.....	11-5	11-23

CHAPTER 12. TEMPEST-SHIELDED FACILITIES

Outline.....	12-1	12-1
Introduction.....	12-2	12-2
Design criteria for 50-decibel facilities.....	12-3	12-2
RF shield design for 50-decibel facilities.....	12-4	12-3
Penetration protection devices.....	12-5	12-10
Cited references.....	12-6	12-11
Uncited reference.....	12-7	12-11

LIST OF FIGURES

Figure 2-1.	The Compton process.....	2-25
2-2.	(Not used.)	
2-3.	Variations in high-altitude EMP peak electric field strength as a function of direction and distance from surface zero.....	2-27
2-4.	HEMP waveform.....	2-28
2-5.	Qualitative time domain example of HEMP.....	2-29
2-6.	Qualitative frequency domain example of HEMP.....	2-30
2-7.	Surface-burst EMP showing source region and radiated region.....	2-31
2-8.	Overview of surface-burst EMP.....	2-32
2-9.	Radiated vertical electric field--large surface burst.....	2-33
2-10.	Air-burst EMP--source region.....	2-34
2-11.	Air-burst EMP--radiated region.....	2-35
2-12.	Three modes of penetration and coupling into shielded enclosures.....	2-36
2-13.	Magnetic shielding effectiveness of an enclosure with solid walls and an enclosure with rebar.....	2-37
2-14.	Magnetic shielding effectiveness of an ideal enclosure and an enclosure with openings.....	2-38
2-15.	Ground-based facilities--unintentional antennas.....	2-39
2-16.	EMP coupling to facility penetrations.....	2-40
2-17.	Two mechanisms by which EMP couples to conductors.....	2-41
2-18.	Equivalent circuit for a small electric dipole.....	2-42
2-19.	Equivalent circuit for a small loop (magnetic dipole).....	2-43
2-20.	Modeling example--microwave tower and equivalent fat cylindrical monopole.....	2-44
2-21.	Shielded cables and transfer impedance.....	2-45

LIST OF FIGURES (continued)

	<u>Page</u>
Figure 2-22.	Transmission line coupling..... 2-46
2-23.	Aerial conductors: effect of conductor length..... 2-47
2-24.	Buried conductors: effect of burial depth..... 2-48
2-25.	Ringings..... 2-49
2-26.	Typical internal signal cable distribution diagram..... 2-50
2-27.	Intrasite cables..... 2-51
2-28.	EMP system interaction..... 2-52
2-29.	Energy level ranges, in joules, that damage various components..... 2-53
2-30.	Examples of transient upset..... 2-54
2-31.	Range of pulse power damage constants for representative transistors..... 2-55
2-32.	Range of pulse power damage constants for representative semiconductors..... 2-56
3-1.	Building examples showing three concepts for critical equipment protection..... 3-11
3-2.	Zonal shielding concept..... 3-12
3-3.	Underground facility with four zones..... 3-13
3-4.	Zonal shielding concept with steel-reinforced concrete as shield 1..... 3-14
3-5.	Shielded enclosure: cable entry vault..... 3-15
3-6.	Optical fiber shield penetration..... 3-16
4-1.	Processes and currents occurring in a flash to ground..... 4-12
4-2.	EMP and lightning comparison..... 4-13
4-3.	Sample power line surge voltage as a function of distance from stroke to line..... 4-14
4-4.	Typical spectrum of lightning radiated E-field..... 4-15
4-5.	Average radiated and static fields for lightning..... 4-16
5-1.	Transmission line model of shielding..... 5-97
5-2.	Correction factor in correction term for internal reflections..... 5-98
5-3.	Shield absorption loss nomograph..... 5-99
5-4.	Nomograph for determining magnetic field reflection loss..... 5-100
5-5.	Nomograph for determining electric field reflection loss..... 5-101
5-6.	Nomograph for determining plane wave reflection loss..... 5-102
5-7.	Chart for computing K for magnetic field secondary reflection loss..... 5-103

LIST OF FIGURES (continued)

	<u>Page</u>
Figure 5-8. Chart for computing secondary losses for magnetic fields. X.....	5-104
5-9. Absorption loss for steel and copper shields at 30 hertz to 10,000 megahertz.....	5-105
5-10. Absorption loss for copper and iron, in decibels per mil. X.....	5-106
5-11. Shielding effectiveness in electric, magnetic, and plane wave fields of copper shields (7 mils thick) for signal sources 165 feet from the shield. X.....	5-107
5-12. Shielding effectiveness in electric, magnetic, and plane wave fields of steel shield (1 mil thick) for signal sources 165 feet from the shield. X.....	5-108
5-13. Shielding effectiveness in electric, magnetic, and plane wave fields of steel shield (50 mils thick) for signal sources 165 feet from the shield. X.....	5-109
5-14. Minimum shielding effectiveness of low-carbon steel walls. X.....	5-110
5-15. Performance characteristics of typical commercial shielded enclosures. X.....	5-111
5-16. Mean shielding effectiveness for all test points for the June 1980 test. X.....	5-112
5-17. (Not used.)	
5-18. Aperture shielding. X.....	5-114
5-19. (Not used.)	
5-20. (Not used.)	
5-21. (Not used.)	
5-22. Attenuation--rectangular waveguide.....	5-119
5-23. Attenuation--circular waveguide.....	5-120
5-24. Air impedance of perforated metal and honeycomb.....	5-121
5-25. Air impedance of copper and nickel mesh.....	5-122
5-26. (Not used.)	
5-27. Center area attenuation of 5-meter-high, single-course reinforcing steel room.....	5-124
5-28. Center area attenuation of 10-meter-high, single-course reinforcing steel room.....	5-125
5-29. Correction curves for various rebar diameters and spacings using single-course rebar construction. X.....	5-126
5-30. Shielding degradation versus distance from wall.....	5-127
5-31. Shielding effectiveness of reinforcement steel.....	5-128
5-32. Reinforcement steel welding practice.....	5-129

LIST OF FIGURES (continued)

	<u>Page</u>
Figure 5-33. Schematic presentation--reinforcement steel shield.....	5-130
5-34. Weld joints for sheet steel shields.....	5-131
5-35. Bolted joints for metallic shields.....	5-132
5-36. Shielding effectiveness for bolted joints.....	5-133
5-37. Influence of screw spacing on shielding effectiveness.....	5-134
5-38. Gasket deflection limits (in inches).....	5-135
5-39. Typical mounting techniques for RF gaskets.....	5-136
5-40. Improper gasket application.....	5-137
5-41. EMI shielded door seam (mesh gasket).....	5-138
5-42. EMI shielded door seam ("oval" spiral gasket).....	5-139
5-43. EMI shielded door seam (fingerstock).....	5-140
5-44. Shielding effectiveness and transfer impedance.....	5-141
5-45. A braided-shield coaxial cable.....	5-142
5-46. Cable shielding effectiveness with number of braid layers.....	5-143
5-47. Lossy conductor construction.....	5-144
5-48. Attenuation of HEMP interference propagating on lossy-wrapped conductors.....	5-145
5-49. Induction loop area for twisted pair cables.....	5-146
5-50. Experiments with shielded twisted pair cabling.....	5-147
5-51. Construction of some popular coaxial connectors.....	5-148
5-52. Contact resistance of conductive coatings on aluminum.....	5-149
5-53. Shielding effectiveness of connectors with various finishes.....	5-150
5-54. Effect of tightening torque on shielding effectiveness during vibration.....	5-151
5-55. Effect of added spring fingers on shielding effectiveness.....	5-152
5-56. Effect of adding shielding gaskets on connector shielding effectiveness.....	5-153
5-57. Normalized transfer impedance for solid cylindrical shields.....	5-154
5-58. Magnitude of the transfer impedance of rigid steel conduit.....	5-155
5-59. Flaw impedance (Z_F) of typical coupling.....	5-156
5-60. Diffusion signal for 1-inch galvanized steel conduit showing sense wire voltage.....	5-157
5-61. Flaw impedance (Z_F) of 0.038-millimeter (0.015-inch) wall flex-joint with and without copper strap.....	5-158

LIST OF FIGURES (continued)

	<u>Page</u>
Figure 5-62. Flaw impedance (Z_F) of 0.76-millimeter (0.03-inch) wall flex-joint with and without copper strap.....	5-159
5-63. Experimental HEMP hardened union.....	5-160
5-64. Type C conduit body.....	5-161
5-65. Machined conduit body cover for HEMP hardening.....	5-162
5-66. "Wrap-around" junction box cover.....	5-163
5-67. (Not used.)	
5-68. (Not used.)	
5-69. (Not used.)	
5-70. (Not used.)	
5-71. The four basic filter classes.....	5-168
5-72. Ferrite bead on wire and ferrite bead equiv- alent circuit.....	5-169
5-73. Filter pin connector design.....	5-170
5-74. Shunt and series transformer wiring configuration.....	5-171
5-75. Typical shielded door closures.....	5-172
5-76. Emergency escape hatch configuration.....	5-174
5-77. Typical welded screen installation over a ventilation aperture.....	5-175
5-78. Typical clamped screen installation over a ventilation aperture.....	5-176
5-79. Honeycomb material for shielding air vents.....	5-177
5-80. Waveguide attenuation as a function of waveguide dimensions.....	5-178
5-81. Air vent HEMP protection design.....	5-179
5-82. Conduit or metal pipe penetration design.....	5-180
5-83. HEMP protection for waveguide entry.....	5-181
5-84. Plastic pipe termination practices.....	5-182
5-85. Theoretical attenuation of the TE_{11} mode for a 1.5-inch (3.8-centimeter) internal diameter pipe with distilled water for various loss tangents.....	5-184
5-86. Cutoff frequency versus relative dielectric constant for various pipe diameters.....	5-185
5-87. Effects of poor bonding on the performance of a power line filter.....	5-186
5-88. Bolted bond between flat bars.....	5-187
5-89. Bracket installation (bolt).....	5-188
5-90. Bonding of connector to mounting surface.....	5-189
5-91. Bolting of bonding jumpers to flat surface.....	5-190
5-92. Bonding to rigid conduit.....	5-191
5-93. Equivalent circuit for bonding strap.....	5-192

LIST OF FIGURES (continued)

	<u>Page</u>
Figure 5-94. True equivalent circuit of a bonded system.....	5-193
5-95. Techniques for protecting bonds between dissimilar metals.....	5-194
5-96. Zonal grounding.....	5-195
5-97. Minimum earth electrode system configuration for rectangular-shaped facility.....	5-196
5-98. Electrode configuration for irregular-shaped facility.....	5-197
5-99. Current path on zonal boundaries.....	5-198
5-100. Typical hybrid ground configuration.....	5-199
5-101. Typical ground configurations for HEMP protection.....	5-200
6-1. Bounded wave simulators.....	6-43
6-2. Pulsed radiated wave simulators.....	6-44
6-3. Continuous wave testing--CW test configuration.....	6-46
6-4. Direct current injection testing.....	6-47
6-5. Inductive current injection testing.....	6-48
6-6. Direct drive test for penetrating conductor (conceptual sketch).....	6-49
6-7. Transfer impedance/admittance test setup.....	6-50
6-8. Alternative demonstration and test methods.....	6-51
6-9. Response characteristic measurement.....	6-52
6-10. Standard circuit for measuring S parameters.....	6-53
6-11. Response measurement.....	6-54
6-12. HEMP stress test.....	6-55
6-13. TPD power attenuation test.....	6-56
6-14. Alternative power attenuation test using simulated subsystem impedance.....	6-57
6-15. Static breakdown voltage measurement.....	6-58
6-16. Small-loop-to-small-loop test setup.....	6-59
6-17. Proposed measurement points for small-loop test.....	6-60
6-18. Test setup for Helmholtz coil field generation.....	6-61
6-19. Parallel strip line technique.....	6-62
6-20. Attenuation measurement--high-impedance electric field.....	6-63
6-21. Attenuation test for plane waves (wave impedance = 377 ohms).....	6-64
6-22. Parallel plate line.....	6-65
6-23. Sweep frequency bonding measurement system.....	6-66
7-1. Effect of hardening approach on subsystem design.....	7-15
7-2. Interaction of HM/HS/TSM program elements.....	7-16

LIST OF FIGURES (continued)

	<u>Page</u>
Figure 7-3.	Configuration management process..... 7-17
7-4.	Example of maintenance procedures..... 7-18
8-1.	Near-surface and exoatmospheric blasts..... 8-13
8-2.	Time waveform for the free-field HEMP electric field..... 8-14
8-3.	HEMP ground coverage for bursts of various heights above the United States..... 8-15
8-4.	Reasonable worst-case TEMPEST shielding attenuation requirement..... 8-16
8-5.	Fifty-decibel (nominal) TEMPEST pipe or air duct penetration design..... 8-17
11-1.	Required electromagnetic attenuation..... 11-32
11-2.	Checklist for HEMP drawings..... 11-33
12-1.	Efficient TEMPEST facility floor plan..... 12-12
12-2.	Typical clamped modular shield room joints..... 12-13
12-3.	Typical penetration panel installation in a modular shielded enclosure..... 12-14
12-4.	Steel plate floor shield design..... 12-15
12-5.	Floor plate shield construction technique..... 12-16
12-6.	Foil wall shield construction technique..... 12-17
12-7.	Foil/foil seam..... 12-18
12-8.	Sheet metal/foil seam..... 12-19
12-9.	Foil shield pipe penetration design..... 12-20

LIST OF TABLES

Table 2-1.	Important features of EMP environments..... 2-21
2-2.	EMP waveform summary..... 2-22
2-3.	Response thresholds..... 2-23
2-4.	Typical EMP transients and equipment thresholds--EMP threat level..... 2-24
4-1.	HEMP/TEMPEST-related standards and specifications..... 4-8
4-2.	Peak magnetic field values for close lightning strokes..... 4-11
5-1.	Coefficients for magnetic field reflection loss..... 5-69
5-2.	Absorption loss of metals at 150 kilohertz..... 5-70
5-3.	Absorption loss of solid copper, aluminum, and iron shields at 60 hertz to 10,000 megahertz..... 5-71
5-4.	Reflection loss..... 5-72

LIST OF TABLES (continued)

	<u>Page</u>
Table 5-5. Shield effectiveness in magnetic field (wave impedance much smaller than 377 ohms) of solid copper, aluminum, and iron shields for signal source 12 inches from the shield at 150 kilohertz to 100 megahertz.....	5-73
5-6. Shielding effectiveness in plane wave field (wave impedance equal to 377 ohms) of solid copper and iron shields for signal sources greater than 2 inches from the shield at 150 kilohertz to 100 megahertz.....	5-74
5-7. Shielding effectiveness in electric field (wave impedance much greater than 377 ohms) of solid copper, aluminum, and iron shields for signal source 12 inches from the shield at 0.15 megahertz to 100 megahertz.....	5-75
5-8. Re-reflection (B) factors in electric, magnetic, and plane wave fields of solid copper and iron shields.....	5-76
5-9. Shielding effectiveness in electric, magnetic, and plane wave fields of copper shield (7 mils thick) for signal source 165 feet from the shield at 30 hertz to 10 gigahertz.....	5-78
5-10. Shielding effectiveness in electric, magnetic, and plane wave fields of steel shield (1 mil thick) for signal source 165 feet from the shield at 30 hertz to 10 gigahertz.....	5-79
5-11. Shielding effectiveness in electric, magnetic, and plane wave fields of steel shield (50 mils thick) for signal source 165 feet from the shield at 30 hertz to 10 gigahertz.....	5-80
5-12. Sample calculations of shielding effectiveness for solid metal shield.....	5-81
5-13. Peak voltage induced on 10-meter radius loop inside 10-meter radius spherical shield by the high-altitude EMP (by diffusion through the walls only).....	5-83
5-14. Effectiveness of nonsolid shielding materials against low-impedance and plane waves.....	5-84
5-15. Effectiveness of nonsolid shielding materials against high-impedance waves.....	5-85
5-16. Comparison of measured and calculated values of shielding effectiveness for No. 22, 15-mil copper screens.....	5-86
5-17. (Not used.)	

LIST OF TABLES (continued)

	<u>Page</u>
Table 5-18. Application factors for welded wire fabric.....	5-88
5-19. Typical values of conductivity for soils and rock.....	5-89
5-20. Skin depth (d) and absorption loss (A) for nonmetal materials.....	5-90
5-21. Electromotive series.....	5-91
5-22. Characteristics of conductive gasketing materials.....	5-92
5-23. (Not used.)	
5-24. Comparison of protection devices.....	5-94
5-25. Galvanic series for selected metals.....	5-95
5-26. Relative advantages and disadvantages of the principal types of earth electrodes.....	5-96
6-1. Test applicability.....	6-37
6-2. Summary of existing bounded-wave simulators.....	6-38
6-3. Summary of radiating wave simulators.....	6-39
6-4. Scaling relationships.....	6-40
6-5. Summary of quality assurance test methods.....	6-41
6-6. Comparison of shielding effectiveness test methods.....	6-42
7-1. Qualitative tradeoff study results.....	7-14
8-1. Comparison of HEMP with lightning-induced stresses on long overhead power lines.....	8-12
11-1. Power line surge arrester criteria.....	11-26
11-2. Power line filter criteria.....	11-27
11-3. Signal and control line protection: coaxial penetrations.....	11-28
11-4. Twisted shielded pair criteria.....	11-29
11-5. Terminal protection device.....	11-30
11-6. Shielding effectiveness test points.....	11-31